

Simplified procedure in case of an accident

Contaminated solution spillage

- Place dry paper towels on the liquid or contaminated surface.
- Deposit 2% bleach on paper towels (do not use a spray).
- Let it rest for 30 minutes and then pick up the contaminated paper from the outside in.
- Wipe as many times as necessary with paper towels soaked in 2% bleach, always from the outside to the inside of the stain.
- Rinse with water and wipe off.
- Dispose of all used paper in the red garbage can.
- Inform the laboratory respondent.

Injuries with contaminated material

- Make the wound bleed profusely.
- Clean the wound with soap.
- Notify the laboratory respondent.
- If necessary, go to the HUG emergency room.
- If appropriate, notify the professional accident insurance

Splash with contaminated solution

- Immediately remove the contaminated piece(s) of clothing (protective gown, clothing, etc.).

Depending on the extent of the contamination:

- Throw the protective gown in the red trash can.
- Rinse the other pieces of clothing thoroughly with disinfectant and put them in an autoclavable red bag.
- Shower and apply disinfectant detergent, leave for 30 minutes, rinse thoroughly with water.
- Notify the laboratory respondent.