



## RULES FOR THE RECUPERATION OF P2 WASTE



Red rigid containers are the only ones accepted by the Laboratory Support Service (LSS) for P2 waste collection and autoclave inactivation.

Red bags are no longer collected. If you use them, you must place them **open** in the red containers provided by the SSL, which is responsible for the autoclave inactivation of your P2 waste.



### GOAL AND USING THE RED CONTAINER

This container is exclusively intended for single-use P2 waste, so there's no need to line it with a red bag.

### DISPOSAL PROCESS FOR EACH CONTAINER P2

#### Terms and conditions:

The partner laboratories are fully committed to the diligent execution of the P2 container acceptance conditions, in accordance with the following provisions:

- P2 waste must not exceed the limit indicated in yellow above.
- Containers must be properly closed (clips).
- Containers must be disinfected by P2 laboratory staff, according to the procedure and disinfectant specific to each laboratory's P2 activity:
  - This procedure must be validated by the BSO and STEPS and communicated to the SSL manager (P. Brawand - Pierre.Brawand@unige.ch).
  - Disinfection must ensure that the containers can be handled without gloves by staff outside the laboratory.
- Containers must be marked with the following indications on the appropriate sticker or with an indelible black pen:
  - **Name of group leader**
  - **Room number**
  - **Composition of contents: AGAR or SOLID**
  - **Disinfection carried out**
  - **Containers must bear the "biohazard" sticker.**



NB: No container will be accepted if it does not meet the above requirements.

### STORAGE AND TRANSPORT :

- Containers **will be stored exclusively in P2.**
- Transport and disposal will be carried out by SSL personnel, if necessary by waste producers, to the inactivation center (E07.2552.a).

### **INACTIVATION :**

- Inactivation is entirely handled by the SSL, which will then dispose of the waste in the yellow waste stream, in accordance with the appropriate procedure.

### **RED CONTAINER SUPPLY PROCESS:**

- In each P2 laboratory, for every container used, an empty container will be provided.
- Renewals can be made via your SSL agent (verbal or e-mail).

### **CONTACTS :**

#### Structure manager :

- P. Brawand
- Tel : 95 397
- Mail : [Pierre.Brawand@unige.ch](mailto:Pierre.Brawand@unige.ch)

#### location:

- E07.2552.a
- Tel : 95648
- Agent : En fonction du planning